# 3 Port Solenoid Valve Series SYJ300/500/700

Rubber Seal





### Improved pilot valve

Pilot valve cover is stronger using stainless steel. Mounting thread is also reinforced from size M1.7 to M2.


#### •Flow Characteristics

Series	Flow characteristics						
Selles	C [dm³/(s·bar)]	b	Cv				
SYJ300	0.36	0.31	0.089				
SYJ500	1.2	0.41	0.32				
SYJ700	2.7	0.38	0.72				



# Rubber Seal 3 Port Solenoid Valve Series SYJ300/500/700

Variations



Note) All AC voltage models have built-in surge voltage suppressor.




# Series SYJ300/500/700

Series SYJ700

# **Manifold Variations**

						A po	ort size					
Maharandara	A port	P, R ports				With one-touch fitting						
Valve series	location	size	M3	M5	1/8	Applicable tubing O.D.						
						ø4	ø6	ø8	N3	N7	N9	
- SYJ300	Тор	M5 x 0.8	Note 1)		_							
P.1378		1/8	Note 2)									
P.1378 P.1378 P.1392 P.1392	Тор	1/8	_	•	_	—	_	_	_	_	—	
<sup>®</sup> SYJ700	Тор	1/8			Note 1)							
P.1410	100	1/4	_			—	_					
न्न SYJ300	Side	M5 x 0.8	Note 1)	_		—	_				—	
SYJ300 P.1378 SYJ500 P.1392 SYJ700	Side	1/8	_		—					_	_	
	Bottom	1/0	—	$\bullet$		_			_	_	_	
<b>SYJ500</b> P.1392	Side	1/8	—									
ase	Bottom	1/8	—	—	Note 1)	—	-		—	—	_	
<b>ŠYJ700</b>	Bollom	1/4	—				— _					
P.1410	Side	1/4										
Note 1) Only for Note 2) Only for												




Series SYJ300

Series SYJ500

SYJ VQZ VP VG VP3□

# **Rubber Seal 3 Port Pilot Solenoid Valve** Series SYJ300



Body ported



Base mounted

#### Specifications

Fluid		Air			
Operating pressure range (MPa)	Internal pilot	0.15 to 0.7			
Ambient and fluid ter	nperature (°C)	-10 to 50 (No freezing.)			
Response time ms (a	t 0.5 MPa) Note 1)	15 or less			
Max. operating freque	ency (Hz)	10			
Manual override (Manual operation)		Non-locking push type, push-turn locking slotted type, push-turn locking lever type			
Pilot exhaust method		Individual exhaust for the pilot valve, common exhaust for the pilot and main valve			
Lubrication		Not required			
Mounting orientation		Unrestricted			
Shock/Vibration resis	stance (m/s²) Note 2)	150/30			
Enclosure		Dust proof (* M8 connector conforms to IP65.)			
<ul> <li>* Based on IEC60529</li> <li>Note 1) Based on dynamic performance test, JIS B 8374-1981. (Coil temperature: 20°C, at rated voltage, without surge voltage suppressor.)</li> <li>Note 2) Impact resistance: No malfunction occurred when it is tested in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition.</li> </ul>					

(Value in the initial state) Vibration resistance: No malfunction occurred in one sweep test between 45 and 2000 Hz.

Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Value in the initial state)

### Solenoid Specifications

#### Grommet (G), (H), L plug connector (L), **Electrical entry** M plug connector (M), M8 connector (W) Coil rated DC 24, 12, 6, 5, 3 voltage (V) AC 50/60 Hz 100, 110, 200, 220 Allowable voltage fluctuation ±10% of rated voltage Standard 0.35 (With light: 0.4) Power DC With power consumption (W) 0.1 (With light only) saving circuit 0.78 (With light: 0.81) 100 V 0.86 (With light: 0.89) 110 V [0.94 (With light: 0.97)] [115 V] Apparent power AC (VA) \* 200 V 1.18 (With light: 1.22) 220 V 1.30 (With light: 1.34) [230 V] [1.42 (With light: 1.46)] Surge voltage suppressor Diode (varistor when non-polar types) Indicator light I ED

\* In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC. \* For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage. \* S, Z and T type (with power saving circuit) should be used within the following allowable voltage fluctuation range due to a voltage drop caused by the internal circuit. S and Z type: 24 VDC: -7% to +10%


12 VDC: -4% to +10%

T type: 24 VDC: -8% to +10%

12 VDC: -6% to +10%




#### Internal pilot




#### External pilot

SYJ31<sup>2</sup>₄R

SYJ32<sup>2</sup>₄R







1372

#### Rubber Seal 3 Port Pilot Solenoid Valve Series SYJ300

### Flow Characteristics/Mass

		<b>-</b> (				Flow char	racteristics			Effective	Mass (g) Note)		
Valve r	nodel	Type of actuation	Port size	1	1→2 (P→A)		2→3 (A→R)		area		L/M plug	M8	
		actuation	size	C [dm <sup>3</sup> /(s bar)]	b	Cv	C [dm <sup>3</sup> /(s bar)]	b	Cv	(mm²)	Grommet	connector	connector
Body	SYJ312	N.C.	M0 v 0 F	_	_	-	_	-	-	0.0	32	00	37
ported	SYJ322	N.O.	M3 x 0.5	_	_	_	_	_	_	0.9	32	33	3/
Base mounted	SYJ314	N.C.	M5 x 0.8	0.41	0.18	0.086	0.35	0.33	0.086		53 (32)	F4 (00)	F0 (07)
(with sub-plate)	SYJ324	N.O.	0.0 X CIVI	0.36	0.31	0.089	0.36	0.31	0.089	-	55 (52)	54 (33)	58 (37)

Note) Value for DC. Add 1 g for AC. ( ): Without sub-plate.


# **External Pilot**

# SYJ300R

Pilot valve pressure is supplied separately from the main valve pressure through the use of a separate supply port. It can be used in the vacuum (up to -100 kPa) or low pressure line with 0.15 MPa or less.

### **Specifications**


Applicable model	Base mounted	SYJ314R, SYJ324R)		
Operating pressure range	Main pressure	-100 kPa to 0.7		
МРа	External pilot pressure	0.15 to 0.7		



Note 1) For manifold base, refer to page 1378. Note 2) External pilot type body ported valves (SYJ3□2R) can only be used on the manifold.


SYJ
VQZ
VP
VG
VP3🗆


# How to Order



### Rubber Seal 3 Port Pilot Solenoid Valve Series SYJ300


### Construction





#### **Replacement Parts**

No.	Description	Part no.	Note
6	Sub-plate Note)	SYJ300-9-1(-Q)	Zinc die-casted
7	Pilot valve	V111(T)-□□□□	



#### **Component Parts**

No.	Description	Material	Note
1	Body	Zinc die-casted	White
2	Piston plate	Resin	White
3	End cover	Resin	White
4	Piston	Resin	-
5	Spool valve assembly	Aluminum, H-NBR	_

#### V111 5 G Coil specifications Light/surge voltage suppressor Nil Standard With power Nil Without light/surge voltage suppressor saving circuit т S With surge voltage suppressor (24, 12 VDC only) Z With light/surge voltage suppressor \* Power saving circuit **R** With surge voltage suppressor (Non-polar type) is not available in the U With light/surge voltage suppressor (Non-polar type) case of W□ type. \* For AC voltage valves there is no "S" Rated voltage option. It is already built-in to the rectifier circuit. 24 VDC 5 \* For "R" and "U", DC voltage is only 6 V S R 12 VDC available. 6 VDC 5 VDC \* Power saving circuit is only available in the "Z" type. 3 VDC **Electrical entry** 10<u>0 VAC 50/60 Hz</u> 1 G Grommet, 300 mm lead wire 2 200 VAC 50/60 Hz 110 VAC 50/60 Hz Н Grommet, 600 mm lead wire 3 [115 VAC 50/60 Hz] With lead wire Т L plug 220 VAC 50/60 Hz LN Without lead wire 4 connector [230 VAC 50/60 Hz] LO Without connector ∗ For type W□, DC М With lead wire M plug voltage is only MN Without lead wire connector available. МО Without connector CE-compliant: For DC wo Without connector cable M8 only. With connector cable Note 1) W□ connector For connector cable of M8 connector, refer to page 1429. Note 1) Enter the cable length symbols in □. Please be sure to fill in the blank referring to page 1429.

J Since V111 is CE-compliant as standard, the suffix "-Q" is not necessary.


# How to Order Pilot Valve Assembly

SYJ
VQZ
VP
VG
VP3🗆



# **Body Ported**


D<sub>\*[]</sub> for AC





#### L plug connector (L): SYJ3 2- L - M3

M plug connector (M): SYJ3□2-□M□□-M3

#### M8 connector (WO): SYJ3□2-□WO□□-M3








\* Refer to page 1429 for dimensions with connector cable.


1376




-


### **Base Mounted (With Sub-plate)**






#### M8 connector (WO): SYJ304-0WO00-M5







\* Refer to page 1429 for dimensions with connector cable.

SYJ

VQZ

VP

VG

VP3□

# Series SYJ300 Manifold Specifications



### **Manifold Specifications**

Model	For internal pilot	Type 20	Type 41, S41	Type 42, S42		
Woder	For external pilot	Type 20R	—	Type 42R, S42R		
Manifold type			Single base	e/B mount		
P (SUP), R (EXH)		Common SUP/Common EXH				
Valve stations			stations			
A port	Location	Valve	Base			
Porting specifications	Direction	Тор	Side			
	P, R port	M5 x 0.8 1/8	M5 x 0.8	1/8		
Port size	A port	M3 x 0.5	M3 x 0.5	M5 x 0.8 C4 (One-touch fitting ø4)		
	X port Note)	M5 x 0.8	—	M5 x 0.8		

### **Flow Characteristics**

			Port size		Flow characteristics					Effective	
	Manifald		I UIT SIZE		1	1→2 (P→A)			2→3 (A→R)		
	Manifold		1(P), 3(R) Port	2(A) Port	C [dm³/(s·bar)]	b	Cv	C [dm³/(s·bar)]	b	Cv	area (mm²)
Body ported for internal pilot	Type SS3YJ3-20	SYJ3⊡2	M5 x 0.8	M3 × 0.5	-	_	-	_	_	_	0.9
	Type SS3YJ3- 41 S41	SYJ3⊡4	M5 x 0.8	M3 x 0.5	-	_	_	_	_	_	1.5
Base mounted	Type SS3YJ3-42-M5	SYJ3⊡4	1/8	M5 x 0.8	0.31	0.17	0.075	0.32	0.11	0.072	-
for internal pilot	Type SS3YJ3-42-C4	51334	1/0	C4	0.33	0.36	0.086	0.33	0.2	0.082	_
	Type SS3YJ3-S42-M5			M5 x 0.8	0.32	0.3	0.079	0.33	0.35	0.086	-
	Type SS3YJ3-S42-C4	SYJ3⊡4	1/8	C4	0.35	0.17	0.082	0.35	0.26	0.086	_
Body ported for external pilot	Type SS3YJ3-20R	SYJ3⊡2R	1/8	M3 x 0.5	_	_	-	_	-	-	0.9
	Type SS3YJ3-42R-M5		4/0	M5 x 0.8	0.31	0.17	0.075	0.32	0.11	0.072	_
Base mounted	Type SS3YJ3-42R-C4	SYJ3⊡4R	1/8	C4	0.33	0.36	0.086	0.33	0.20	0.082	_
for external pilot	Type SS3YJ3-S42R-M5	SYJ3⊡4R	1/0	M5 x 0.8	0.32	0.30	0.079	0.33	0.35	0.086	_
	Type SS3YJ3-S42R-C4	51J3  4R	1/8	C4	0.35	0.17	0.082	0.35	0.26	0.086	_

Note) Value at manifold base mounted, 2 position single acting

### How to Order Manifold (Example)

Instruct by specifying the valves and blanking plate as with the manifold base model no.	sembly to be mounted on the manifold along
(Example)	
SS3YJ3-20-03 ········· 1 set (manifold base)	SS3YJ3-42R-03-C4 ···· 1 set (manifold base)
* SYJ312-5LZ-M3 2 sets (valve)	SYJ314R-5G ······ 2 sets (valve)
*SYJ300-10-1A 1 set (blanking plate assembly)	SYJ300-10-2A 1 set (blanking plate assembly)
└→ The asterisk denotes the symbol for assembly. Prefix	it to the part nos. of the solenoid valve, etc.


( )

#### Combinations of Solenoid Valve, Manifold Gasket and Manifold Base

**Base mounted** 

(Type SYJ3□4(R)(-Q))

Body ported (Type SYJ3□2(R)(-Q))




Round head combination screw SY100-33-3 (M1.7 x 17, Matt nickel plated) Manifold gasket SYJ300-5-4 Applicable base

Applicable base SS3YJ3-20(-Q) | Manifold SS3YJ3-20R(-Q) | base Applicable base Sub-plate SS3YJ3-41(-Q) SS3YJ3-S41(-Q) SS3YJ3-S42(-Q) SS3YJ3-S42(-Q) SS3YJ3-42R(-Q) SS3YJ3-S42R(-Q)

#### **Blanking Plate Assembly**

Part no.: SYJ300-10-1A(-Q)

Part no.: SYJ300-10-2A(-Q)



Note) Add suffix "-Q" for the CE-compliant product.

# \land Caution


Mounting screw tightening torques


M1.7: 0.12 N·m

Use caution to the assembly orientation for solenoid valves, gasket and optional parts.

SYJ
VQZ
VP
VG
VP3🗆


### Manifold for Internal Pilot Type






# Rubber Seal 3 Port Pilot Solenoid Valve Series SYJ300







L plug connector (L)




#### M plug connector (M)



#### M8 connector (WO)





# Refer to page 1429 for dimensions with connector cable.


Station n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	35.5	46	56.5	67	77.5	88	98.5	109	119.5	130	140.5	151	161.5	172	182.5	193	203.5	214	224.5
L2	28.5	39	49.5	60	70.5	81	91.5	102	112.5	123	133.5	144	154.5	165	175.5	186	196.5	207	217.5




# Type 41 Manifold: Side Ported/SS3YJ3-41-Stations -M3



#### Grommet (G)





L plug connector (L)



M plug connector (M)

M8 connector (WO)






Refer to page 1429 for dimensions with connector cable.


Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	35.5	46	56.5	67	77.5	88	98.5	109	119.5	130	140.5	151	161.5	172	182.5	193	203.5	214	224.5
L2	28.5	39	49.5	60	70.5	81	91.5	102	112.5	123	133.5	144	154.5	165	175.5	186	196.5	207	217.5


Rubber Seal 3 Port Pilot Solenoid Valve Series SYJ300




# Type 20R Manifold: Top Ported (External Pilot Type)/SS3YJ3-20R-Stations-00

### Grommet (G)










L plug connector (L)


M plug connector (M)

M8 connector (WO)












Station n	Station 2	3	4	5	5	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	47.5	58	68.5	79	89.5	100	110.5	121	131.5	142	152.5	163	173.5	184	194.5	205	215.5	226	236.5
L2	39.5	50	60.5	71	81.5	92	102.5	113	123.5	134	144.5	155	165.5	176	186.5	197	207.5	218	228.5
L3	31.5	42	52.5	63	73.5	84	94.5	105	115.5	126	136.5	147	157.5	168	178.5	189	199.5	210	220.5









One-touch fitting (A port) Applicable tubing O.D.: ø4, ø5/32"

L plug connector (L)


M plug connector (M)


## M8 connector (WO)





\* Refer to page 1429 for dimensions with connector cable.





# **Rubber Seal 3 Port Pilot Solenoid Valve** Series SYJ500



Body ported



Base mounted

#### Specifications

Fluid		Air
Operating pressure range (MPa)	Internal pilot	0.15 to 0.7
Ambient and fluid ter	nperature (°C)	-10 to 50 (No freezing.)
Response time ms (a	t 0.5 MPa) Note 1)	25 or less
Max. operating freque	ency (Hz)	5
Manual override (Mar	nual operation)	Non-locking push type, push-turn locking slotted type, push-turn locking lever type
Pilot exhaust method	I	Individual exhaust for the pilot valve, common exhaust for the pilot and main valve
Lubrication		Not required
Mounting orientation		Unrestricted
Shock/Vibration resis	stance (m/s²) Note 2)	150/30
Enclosure		Dust proof (* DIN terminal, M8 connector conforms to IP65.)
voltage, with Note 2) Impact resis	namic performance ter nout surge voltage supp tance: No malfunction at the right ar and de-energ (Value in the sistance: No malfunction Test was per	on occurred when it is tested in the axial direction and ngles to the main valve and armature in both energized gized states every once for each condition. initial state) on occurred in one sweep test between 45 and 2000 Hz. formed at both energized and de-energized states in the n and at the right angles to the main valve and armature.

### Solenoid Specifications

#### Grommet (G), (H), L plug connector (L), M plug connector (M), DIN terminal (D), (Y), **Electrical entry** M8 connector (W) G, H, L, M, W D, Y Coil rated DC 24, 12, 6, 5, 3 24, 12 voltage (V) AC 50/60 Hz 100, 110, 200, 220 Allowable voltage fluctuation ±10% of rated voltage \* Standard 0.35 (With light: 0.4 (DIN terminal with light: 0.45)) Power With power DC consumption (W) 0.1 (With light only) saving circuit 100 V 0.78 (With light: 0.81) 0.78 (With light: 0.87) 0.86 (With light: 0.89) 0.86 (With light: 0.97) 110 V [115 V] [0.94 (With light: 0.97)] [0.94 (With light: 1.07)] Apparent power AC 1.18 (With light: 1.22) 1.15 (With light: 1.30) 200 V (VA) \* 1.30 (With light: 1.34) 1.27 (With light: 1.46) 220 V [230 V] [1.42 (With light: 1.46)] [1.39 (With light: 1.60)] Surge voltage suppressor Diode (DIN terminal, varistor when non-polar types) Indicator light LED (Neon light when AC with DIN terminal)

\* In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC. \* For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage.

S, Z and T type (with power saving circuit) should be used within the following allowable voltage fluctuation range due to a voltage drop caused by the internal circuit. S and Z type: 24 VDC: -7% to +10%

12 VDC: -4% to +10%


12 VDC: -6% to +10%

T type: 24 VDC: -8% to +10%


### **JIS Symbol**


Internal pilot SYJ51<sup>2</sup>

SYJ52<sup>2</sup>



#### External pilot










### Flow Characteristics/Mass


		Turne of	Port		Flow characteristics							Mass (g) Note)			
Valve n	nodel	Type of actuation			$1 \rightarrow 2 (P \rightarrow A) \qquad \qquad 2 \rightarrow 3 (A \rightarrow R)$				Grommet	L/M plug	DIN	M8			
		actuation	5120	C [dm <sup>3</sup> /(s·bar)]	b	Cv	C [dm³/(s·bar)]	b	Cv	Cionine	connector	terminal	connector		
Body	SYJ512	N.C.	M5 x 0.8	0.53	0.45	0.14	0.47	0.39	0.12	46	47	68	51		
ported	SYJ522	N.O.	0.0 X CIVI	0.66	0.45	0.18	0.66	0.45	0.18	40					
Base mounted			1/8	1.2	0.41	0.32	1.1	0.46	0.32	co (40)	01 (47)	00 (00)			
(with sub-plate)	SYJ524	N.O.	1/0	1.3	0.37	0.33	1.2	0.48	0.34	60 (46)	61 (47)	82 (68)	65 (51)		

Note) Value for DC. Add 3 g for AC. ( ): Without sub-plate.

# **External Pilot**




SYJ
VQZ
VP
VG
VP3🗆




SMC

in the blank referring to page 1429.


## Construction



No.	Description	Material	Note
1	Body	Aluminum die-casted	White
2	Piston plate	Resin	White
3	End cover	Aluminum die-casted	White
4	Piston	Resin	_
5	Spool valve assembly	_	_
6	Spool spring	Stainless steel	-



Bracket assembly SYJ5000-13-3A Note) Add suffix "-Q" for the CE-compliant product.




Since V111 and V115 are CE-compliant as standard, the suffix "-Q" is not necessary.

## **Body Ported**



# Grommet (G), (H): SYJ5 $\Box$ 2- $\Box_{H}^{G}\Box\Box$ -M5


#### With bracket: SYJ5□2-□<sup>G</sup><sub>H</sub>□□-M5-F



### **Base Mounted (With Sub-plate)**



Grommet (G), (H): SYJ5 $\Box$ 4- $\Box_{H}^{G}\Box\Box$ -01 $\Box$ 



18


L plug connector (L): SYJ504-0L00-010

4

M plug connector (M): SYJ504-0M00-010

DIN terminal (D, Y): SYJ5 $\Box$ 4- $\Box_Y^D\Box$  $\Box$ -01 $\Box$ 

M8 connector (WO): SYJ504-0W000-010



dimensions with connector cable.

# Series SYJ500 Manifold Specifications



#### **Manifold Specifications**

	or external pilot	<b>T</b> 04 D								
	or oxtornal phot	Type 21R	Type 40R	Type 41R						
Manifold type			Single bas	se/B mount						
P (SUP), R (EXH)			Common SUP	, common EXH						
Valve stations			2 to 20 stations							
A port Porting	Location	Valve Base								
specifications	Direction	Тор	Bottom	Side						
	P, R port	1/8	1/8	1/8						
Port size	A port	M5 x 0.8	M5 x 0.8 <sup>1/8</sup>	M5 x 0.8, $\frac{1}{8}$ , C4 (One-touch fitting for ø4), C6 (One-touch fitting for ø6)						
	X port Note)	M5 x 0.8	M5 x 0.8	M5 x 0.8						

### **Flow Characteristics**

			Dort	0170			Flow char	acteristics		
54			Port	size		1→2 (P→A)			2→3 (A→R)	
IVI	anifold		1(P), 3(R) port	2(A) port	C [dm³/(s·bar)]	b	Cv	C [dm³/(s·bar)]	b	Cv
Body ported for internal pilot	Type SS3YJ5-20	SYJ5⊡2	1/8	M5 x 0.8	0.47	0.43	0.13	0.74	0.32	0.19
	Type SS3YJ5-40-M5		1/8	M5 x 0.8	0.71	0.52	0.21	0.81	0.28	0.20
	Type SS3YJ5-40-01		1/8	1/8	0.98	0.36	0.25	0.92	0.24	0.22
Base mounted	Type SS3YJ5-41-M5	SYJ5⊡4	1/8	M5 x 0.8	0.71	0.49	0.20	0.80	0.23	0.19
for internal pilot	Type SS3YJ5-41-01		1/8	1/8	1.0	0.37	0.26	0.96	0.25	0.24
	Type SS3YJ5-41-C4		1/8	C4	0.68	0.35	0.17	1.0	0.25	0.24
	Type SS3YJ5-41-C6		1/8	C6	1.0	0.27	0.25	1.0	0.30	0.26
Body ported for external pilot	Type SS3YJ5-21R	SYJ5□2R	1/8	M5 x 0.8	0.47	0.43	0.13	0.74	0.32	0.19
	Type SS3YJ5-40R-M5		1/8	M5 x 0.8	0.71	0.52	0.21	0.81	0.28	0.20
	Type SS3YJ5-40R-01		1/8	1/8	0.98	0.36	0.25	0.92	0.24	0.22
Base mounted	Type SS3YJ5-41R-M5		1/8	M5 x 0.8	0.71	0.49	0.20	0.80	0.23	0.19
for external pilot	Type SS3YJ5-41R-01	SYJ5⊡4R	1/8	1/8	1.0	0.37	0.26	0.96	0.25	0.24
1	Type SS3YJ5-41R-C4		1/8	C4	0.68	0.35	0.17	1.0	0.25	0.24
	Type SS3YJ5-41R-C6		1/8	C6	1.0	0.27	0.25	1.0	0.30	0.26


Note) Value at manifold base mounted, 2 position single operating

### How to Order Manifold (Example)

Instruct by specifying the valves and blanking plate as with the manifold base model no.	sembly to be mounted on the manifold along
(Example)	
SS3YJ5-20-03 ········· 1 set (manifold base)	SS3YJ5-41R-03-C6 ···· 1 set (manifold base)
* SYJ512-5LZ-M5 2 sets (valve)	SYJ514R-5G ······ 2 sets (valve)
* SYJ500-10-1A 1 set (blanking plate assembly) $\top$	SYJ500-10-3A ········· 1 set (blanking plate assembly)
→ The asterisk denotes the symbol for assembly. Prefix	t to the part nos. of the solenoid valve, etc.


### Combinations of Solenoid Valve, Manifold Gasket and Manifold Base

#### **Blanking Plate Assembly**




	SYJ
	VQZ
[	VP
	VG
	VP3🗆

# Manifold for Internal Pilot Type



*∕∂*SMC






M plug connector (M)

DIN terminal (D, Y)

M8 connector (WO)




Refer to page 1429 for dimensions with connector cable.

Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	53	69	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309	325	341
L2	40	56	72	88	104	120	136	152	168	184	200	216	232	248	264	280	296	312	328
L3	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240	256	272	288	304
L4	8	24	40	56	72	88	104	120	136	152	168	184	200	216	232	248	264	280	296

# Type 40 Manifold: Top Ported/SS3YJ5-40-Stations -M5, 01

Sector AC





L plug connector (L)


M plug connector (M)


DIN terminal (D, Y)

M8 connector (WO)










efer to page 1429 for mensions with connector able.

Port size	Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
ME	L1	52	68	84	100	116	132	148	164	180	196	212	228	244	260	276	292	308	324	340
M5	L2	43	59	75	91	107	123	139	155	171	187	203	219	235	251	267	283	299	315	331
1/8	L1	63	80	97	114	131	148	165	182	199	216	233	250	267	284	301	318	335	352	369
1/0	L2	54	71	88	105	122	139	156	173	190	207	224	241	258	275	292	309	326	343	360

#### Rubber Seal 3 Port Pilot Solenoid Valve Series SYJ500





L plug connector (L)


M plug connector (M)


DIN terminal (D, Y)


M8 connector (WO)












Port size	Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
One-touch	L1	50	66	82	98	114	130	146	162	178	194	210	226	242	258	274	290	306	322	338
fitting	L2	41	57	73	89	105	121	137	153	169	185	201	217	233	249	265	281	297	313	329

# Type 41 Manifold: Side Ported/SS3YJ5-41-Stations -M5, 01 □




# Grommet (G)















(Station n) ----- (Station 1)


(Light/surge voltage suppressor)



Port size	Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
ME	L1	52	68	84	100	116	132	148	164	180	196	212	228	244	260	276	292	308	324	340
M5	L2	43	59	75	91	107	123	139	155	171	187	203	219	235	251	267	283	299	315	331
1/8	L1	53	70	87	104	121	138	155	172	189	206	223	240	257	274	291	308	325	342	359
1/0	L2	44	61	78	95	112	129	146	163	180	197	214	231	248	265	282	299	316	333	350

# Type 21R Manifold: Top Ported (External Pilot Type)/SS3YJ5-21R-Stations-00

#### Grommet (G)





L plug connector (L)


M plug connector (M)


**DIN terminal (D, Y)** 


M8 connector (WO)












 Refer to page 1429 for dimensions with connector cable.

Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	62	78	94	110	126	142	158	174	190	206	222	238	254	270	286	302	318	334	350
L2	53	69	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309	325	341
L3	47	63	79	95	111	127	143	159	175	191	207	223	239	255	271	287	303	319	335





L plug connector (L)

M5 x 0.8


(A port)


P=16

M plug connector (M)


21

M8 connector (WO)





**DIN terminal (D, Y)** 




49 (⊕ **°** Ű 58. 66.1 41.1 <u>M8 x</u> 1 58.6


Port size	Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
	L1	62	78	94	110	126	142	158	174	190	206	222	238	254	270	286	302	318	334	350
M5	L2	53	69	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309	325	341
	L3	47	63	79	95	111	127	143	159	175	191	207	223	239	255	271	287	303	319	335
	L1	63	80	97	114	131	148	165	182	199	216	233	250	267	284	301	318	335	352	369
1/8	L2	54	71	88	105	122	139	156	173	190	207	224	241	258	275	292	309	326	343	360
	L3	48	65	82	99	116	133	150	167	184	201	218	235	252	269	286	303	320	337	354



#### Grommet (G)



M plug connector (M) L plug connector (L)



**DIN terminal (D, Y)** 

									-								-			
Port size	Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
On a damak	L1	58	74	90	106	122	138	154	170	186	202	218	234	250	266	282	298	314	330	346
One-touch fitting	L2	49	65	81	97	113	129	145	161	177	193	209	225	241	257	273	289	305	321	337
intung	L3	43	59	75	91	107	123	139	155	171	187	203	219	235	251	267	283	299	315	331


M8 connector (WO)

cable.



#### For M5

#### For 1/8



Port size	Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
	L1	62	78	94	110	126	142	158	174	190	206	222	238	254	270	286	302	318	334	350
M5	L2	53	69	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309	325	341
	L3	47	63	79	95	111	127	143	159	175	191	207	223	239	255	271	287	303	319	335
	L1	63	80	97	114	131	148	165	182	199	216	233	250	267	284	301	318	335	352	369
1/8	L2	54	71	88	105	122	139	156	173	190	207	224	241	258	275	292	309	326	343	360
	L3	48	65	82	99	116	133	150	167	184	201	218	235	252	269	286	303	320	337	354

SYJ
VQZ
VP
VG
VP3🗆



# **Rubber Seal 3 Port Pilot Solenoid Valve** Series SYJ700 ( (




Body ported




Base mounted

#### **JIS Symbol**

Internal pilot



#### External pilot



Specifications
----------------

Fluid		Air			
Operating pressure range (MPa)	Internal pilot	0.15 to 0.7			
Ambient and fluid temperature (°C)		-10 to 50 (No freezing.)			
Response time ms (a	t 0.5 MPa) <sup>Note 1)</sup>	30 or less			
Max. operating freque	ency (Hz)	5			
Manual override (Manual operation)		Non-locking push type, push-turn locking slotted type, push-turn locking lever type			
Pilot exhaust method		Individual exhaust for the pilot valve, common exhaust for the pilot and main valve			
Lubrication		Not required			
Mounting orientation		Unrestricted			
Shock/Vibration resis	stance (m/s²) Note 2)	150/30			
Enclosure		Dust proof (* DIN terminal, M8 connector: IP65)			
<ul> <li>* Based on IEC60529</li> <li>Note 1) Based on dynamic performance test, JIS B 8374-1981. (Coil temperature: 20°C, at rated voltage, without surge voltage suppressor.)</li> <li>Note 2) Impact resistance: No malfunction occurred when it is tested in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Value in the initial state)</li> </ul>					
Vibration resistance: No malfunction occurred in one sweep test between 45 and 2000 H					

Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Value in the initial state)

### **Solenoid Specifications**

Electrical entry			Grommet (G), (H), L plug connector (L), M plug connector (M), DIN terminal (D), (Y), M8 connector (W)		
		G, H, L, M, W	D, Y		
Coil rated	DC		24, 12, 6, 5, 3	24, 12	
voltage (V)	Α	C <sup>50</sup> /60 Hz	100, 110, 200, 220		
Allowable voltage fluctuation			$\pm 10\%$ of rated voltage $^*$		
Power consumption (W)		Standard	0.35 (With light: 0.4 (DIN terminal with light: 0.45))		
	DC With power saving circuit		0.1 (With light only)		
Apparent power (VA) *	AC 20	100 V	0.78 (With light: 0.81)	0.78 (With light: 0.87)	
		110 V [115 V]	0.86 (With light: 0.89) [0.94 (With light: 0.97)]	0.86 (With light: 0.97) [0.94 (With light: 1.07)]	
		200 V	1.18 (With light: 1.22)	1.15 (With light: 1.30)	
		220 V [230 V]	1.30 (With light: 1.34) [1.42 (With light: 1.46)]	1.27 (With light: 1.46) [1.39 (With light: 1.60)]	
Surge voltage suppressor			Diode (DIN terminal, varistor when non-polar types)		
Indicator light			LED (Neon light when AC with DIN terminal)		
A the seminary between 110 VAC and 115 VAC and between 220 VAC and 220 VAC					

) \* In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC.

\* For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage. S, Z and T type (with power saving circuit) should be used within the following allowable voltage fluctuation range due to a voltage drop caused by the internal circuit. S and Z type: 24 VDC: -7% to +10% 12 VDC: -4% to +10%

T type:

24 VDC: -8% to +10% 12 VDC: -6% to +10%

Made to Order (For details, refer to pages 1422 to 1423.)



# Rubber Seal 3 Port Pilot Solenoid Valve Series SYJ700

### Flow Characteristics/Mass

		<b>-</b> (	<b>.</b> .			Mass (g) Note)							
Valve m	nodel	Type of	Port size	-	1→2 (P→A)			2→3 (A→R)		Crommot	L/M plug	DIN	M8
		actuation	size	C [dm3/(s·bar)]	b	Cv	C [dm3/(s·bar)]	b	Cv	Grommet	connector	terminal	connector 80
Body	SYJ712	N.C.	1/8	2.8	0.43	0.77	2.5	0.51	0.76	75	76	97	80
ported	SYJ722	N.O.	1/8	2.7	0.38	0.72	2.4	0.42	0.69	75	70	57	
	SYJ714	N.C.	1/8	2.9	0.32	0.71	2.7	0.34	0.69		) 136 (76)	157 (97)	140 (80)
Base mounted		N.O.	1/0	2.8	0.21	0.70	2.3	0.45	0.63	135 (75)			
(with sub-plate)	SYJ714	N.C.	1/4	3.0	0.31	0.74	2.6	0.33	0.66	135 (75)			
	SYJ724	N.O.	1/4	2.7	0.31	0.68	2.3	0.48	0.64				
Note)	Value for D	C. Add 3	B g for AC	C. (): Withou	ut sub-plate.								


### **External Pilot**

### **SYJ700R**

Pilot valve pressure is supplied separately from the main valve pressure through the use of a separate supply port. It can be used in the vacuum (up to -100 kPa) or low pressure line with 0.15 MPa or less.


### Specifications

Applicable model	Base mounted (S	Base mounted (SYJ714R, SYJ724R)							
Operating pressure range	Main pressure	–100 kPa to 0.7							
MPa	External pilot pressure	0.15 to 0.7							




SYJ
VQZ
VP
VG
VP3🗆


### How to Order



SMC

### Construction







### Component Parts


No.	Description	Material	Note
1	Body	Aluminum die-casted	White
2	Piston plate	Resin	White
3	End cover	Aluminum die-casted	White
4	Piston	Resin	_
5	Spool valve assembly	-	_
6	Spool spring	Stainless steel	_

### How to Order Pilot Valve Assembly



Note) Since V111 and V115 are CE-compliant as standard, the suffix "-Q" is not necessary.






SYJ
VQZ
VP
VG
VP3🗆
L


### **Body Ported**

### Grommet (G), (H): SYJ7□2-□<sup>G</sup><sub>H</sub>□□-01□

# With bracket: SYJ7 $\Box$ 2- $\Box_{H}^{G}$ $\Box$ $\Box$ -01 $\Box$ -F



L plug connector (L): SYJ7□2-□L□□-01□ (-F) M plug connector (M): SYJ7□2-□M□□-01□ (-F) DIN terminal (D, Y): SYJ7□2-□<sup>D</sup>Y□□-01□ (-F) M8 connector (WO): SYJ7□2-□WO□□-01□ (-F)




 Refer to page 1429 for dimensions with connector cable.



### **Base Mounted (With Sub-plate)**

D<sub>\*[]</sub>for AC

### Grommet (G), (H): SYJ7□4-□<sup>G</sup><sub>H</sub>□□-<sup>01</sup><sub>02</sub>□



<sup>\*</sup> Refer to page 1429 for dimensions with connector cable.

# Series SYJ700 Manifold Specifications



### **Manifold Specifications**

Madal	For internal pilot	Type 20	Type 21	Type 40	Type 41	Type 42							
Model	For external pilot	_	Type 21R	—	Type 41R	Type 42R							
Manifold ty	ре	Single base/B mount											
P (SUP), R	(EXH)		Cor	nmon SUP, co	mmon EXH								
Valve static	ons	2 to 20 stations											
A port Porting	Location	Valve	Valve	Base	Base	Base							
specifications	Direction	Тор	Тор	Bottom	Bottom	Side							
	P, R port	1/8	1/4	1/8	1/4	1/4							
Port size	A port	1/8	1/8	1/8	1/8								
	X port Note)	_	M3 x 0.8	_	M5 x 0.8	M5 x 0.8							

Note) Only for external pilot

### **Flow Characteristics**

			Deut	-!			Flow char	acteristics			
	anifold		Port	size		1→2 (P→A)		2→3 (A→R)			
IVI	aniioid		1(P), 3(R) port	2(A) port	C [dm³/(s·bar)]	b	Cv	C [dm³/(s·bar)]	b	Cv	
Body ported	Type SS3YJ7-20	SYJ7⊡2	1/8	1/8	2.2	0.34	0.55	2.3	0.27	0.59	
for internal pilot	Type SS3YJ7-21	513/12	1/4	1/8	2.2	0.39	0.59	2.4	0.32	0.62	
	Type SS3YJ7-40		1/8	1/8	2.1	0.35	0.59	2.3	0.27	0.54	
Base mounted	Type SS3YJ7-41		1/4	1/8	2.2	0.35	0.59	2.4	0.36	0.66	
for internal pilot	Type SS3YJ7-42-01	SYJ7⊡4	1/4	1/8	2.0	0.27	0.47	2.2	0.32	0.56	
for internal pilot	Type SS3YJ7-42-C6		1/4	C6	1.6	0.32	0.39	2.2	0.27	0.54	
	Type SS3YJ7-42-C8		1/4	C8	2.1	0.24	0.51	2.3	0.31	0.59	
Body ported for external pilot	Type SS3YJ7-21R	SYJ7⊡2R	1/4	1/8	2.2	0.34	0.55	2.4	0.32	0.62	
	Type SS3YJ7-41R		1/4	1/8	2.2	0.35	0.59	2.4	0.36	0.66	
Base mounted	Type SS3YJ7-42R-01		1/4	1/8	2.0	0.27	0.47	2.2	0.32	0.56	
for external pilot	Type SS3YJ7-42R-C6	SYJ7⊡4R	1/4	C6	1.6	0.32	0.39	2.2	0.27	0.54	
	Type SS3YJ7-42R-C8		1/4	C8	2.1	0.24	0.51	2.3	0.31	0.59	


Note) Value at manifold base mounted, 2 position single operating

### How to Order Manifold (Example)

Instruct by specifying the valves and blanking plate assembly to be mounted on the manifold along with the manifold base model no.
(Example)
SS3YJ7-20-03 ········· 1 set (manifold base)
SS3YJ7-42R-03-01 ···· 1 set (manifold base)
To asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.

### Combinations of Solenoid Valve, Manifold Gasket and Manifold Base

#### Body ported (Type SYJ7 2(-Q)) Base mounted (Type SYJ7 4(-Q))



Applicable base Type SS3YJ7-20(-Q) Manifold Type SS3YJ7-21(-Q) base Type SS3YJ7-21R(-Q)

Sub-plate Type SS3YJ7-40(-Q) Type SS3YJ7-41(-Q) Manifold Type SS3YJ7-42(-Q) base Type SS3YJ7-41R(-Q) Type SS3YJ7-42R(-Q)

### A Caution


Mounting screw tightening torques

M3: 0.8 N·m


Use caution to the assembly orientation for solenoid valves, gasket and optional parts.

### Blanking Plate Assembly


#### <Standard>



<CE-complaint> Part no.: SYJ700-10-2A-1-Q



### Part no.: SYJ700-10-2A-2-Q




#### Applicable base

Type SS3YJ7-40-Q	1
Type SS3YJ7-41-Q	Manif
Type SS3YJ7-42-Q	base
Type SS3YJ7-41R-Q	2000
Type SS3YJ7-42R-Q	

SYJ
VQZ
VP
VG
VP3🗆

Manifold


### Manifold for Internal Pilot Type



**∂SMC** 


### Type 20 Manifold: Top Ported/SS3YJ7-20- Stations (-00 □)

### Grommet (G)



25

(Station n) ----- (Station 1)





M plug connector (M)

Ф

ØΦ

68.1 [75.1]

65.7

53.5

 $\odot$ 

 $\oplus$ 

3.4

89.6

Max. 10

Pg7

**DIN terminal (D, Y)** 

Ф

00

71.7

83

90.5

/Applicable cable O.D.

ø3.5 to ø7

53.5

3.4

69.3

M8 x 1

76.7

 $\bigcirc$ 

 $\odot$ 

### M8 connector (WO)

53.5

Ф

ΠΦ

Ĥ

cable.

3.4

SYJ

VQZ

VP

VG

VP3□

 $\odot$ 

 $\odot$ 


44


61.5

\* Refer to page 1429 for

dimensions with connector

) [] for AC








### Type 21 Manifold: Top Ported/SS3YJ7-21-Stations (-00 □)

Grommet (G)




L plug connector (L)

M plug connector (M)

DIN terminal (D, Y)

M8 connector (WO)

)




Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	61	80	99	118	137	156	175	194	213	232	251	270	289	308	327	346	365	384	403
L2	49	68	87	106	125	144	163	182	201	220	239	258	277	296	315	334	353	372	391

**SMC** 

### Type 40 Manifold: Top Ported/SS3YJ7-40-Stations -01

### Grommet (G)




L plug connector (L)


M plug connector (M)

**DIN terminal (D, Y)** 


M8 connector (WO)


) [] for AC





Station n Station 2 Station 20 L1 L2 





 Refer to page 1429 for dimensions with connector cable. SYJ

VQZ

VP


VG

VP3🗆

### Type 42 Manifold: Top Ported/SS3YJ7-42-Stations -01, C6, N7 C

### Grommet (G)

For  $_{C8, N9}^{C6, N7} \square$  (Built-in one-touch fitting)




L plug connector (L)

M plug connector (M)

**DIN terminal (D, Y)** 

M8 connector (WO)




Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	61	80	99	118	137	156	175	194	213	232	251	270	289	308	327	346	365	384	403
L2	49	68	87	106	125	144	163	182	201	220	239	258	277	296	315	334	353	372	391

**SMC** 

### Type 41 Manifold: Top Ported/SS3YJ7-41-Stations-01




### Grommet (G)



SYJ
VQZ
VP
VG
VP3🗆

### Type 21R Manifold: Top Ported (External Pilot Type)/SS3YJ7-21R-Stations (-00 )

### Grommet (G)




L plug connector (L)

M plug connector (M)

**DIN terminal (D)** 

### M8 connector (WO)




Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	61	80	99	118	137	156	175	194	213	232	251	270	289	308	327	346	365	384	403
L2	49	68	87	106	125	144	163	182	201	220	239	258	277	296	315	334	353	372	391


**SMC** 


\* [ ] for AC




### Grommet (G)









VQZ

VP

VG

VP3🗆


Station n	Station 2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	Station 20
L1	61	80	99	118	137	156	175	194	213	232	251	270	289	308	327	346	365	384	403
L2	49	68	87	106	125	144	163	182	201	220	239	258	277	296	315	334	353	372	391


Refer to page 1429 for dimensions with connector cable.

# Type 41R Manifold: Bottom Ported (External Pilot Type)/SS3YJ7-41R-Stations-01

Grommet (G)

(Light/surge voltage suppressor)






SYJ
VQZ
VP
VG
VP3🗆



# M8 Connector Conforming to IEC60947-5-2 Series SYJ300/500/700 Made to Order

### How to Order Valve






# *Series SYJ500/700* Made to Order



For detailed specifications, delivery and pricing, please contact SMC.

### **Body Ported External Pilot**

### How to Order Applicable solenoid valve series/SYJ5□2R, SYJ7□2R



• Entry is the same as standard products.

#### **Operating Pressure Range MPa**

Operating pressure range	-100 kPa to 0.7
Pilot pressure range	0.15 to 0.7


#### Dimensions SYJ500: 8 mm longer in total length SYJ700: 8 mm longer in total length


#### **External Pilot Port**

Series	Port size
SYJ500, SYJ700	M5 x 0.8

#### JIS Symbol

#### **Body ported**





SYJ
VQZ
VP
VG
VP3🗆



Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

Manual Override Operation

# \land Warning

When the manual override is operated, connected equipment will be actuated. Confirm safety before operating.

### ■ Non-locking push type [Standard]

Press in the direction of the arrow



### Push-turn slotted locking type [Type D]

While pressing, turn in the direction of the arrow. If it is not turned, it can be operated the same way as the nonlocking type.





### A Caution

When operating the locking type D with a screw driver, turn it gently using a watchmakers screw driver. [Torque: Less than 0.1 N·m]

### Push-turn locking lever type [Type E]

While pressing, turn in the direction of the arrow. If it is not turned, it can be operated the same way as the nonlocking type.





Locked position

### **▲** Caution

When locking the manual override on the push-turn locking types (D, E), be sure to push it down before turning. Turning without first pushing it down can cause damage to the manual override and trouble such as air leakage, etc.

### Solenoid Valve for 200, 220 VAC Specifications

### 🗥 Warning

Solenoid valves with grommet and L/M type plug connector AC specifications have a built-in rectifier circuit in the pilot section to operate the DC coil.

With 200, 220 VAC specification pilot valves, this built-in rectifier generates heat when energized. The surface may become hot depending on the energized condition; therefore, do not touch the solenoid valves.

### Common Exhaust Type for Main and Pilot Valve

### \land Caution

Pilot air is exhausted through the main valve body rather than directly to atmosphere.

- Suitable for applications where exhausting the pilot valve to atmosphere would be detrimental to the surrounding working environment.
- For use in extremely dirty environments where there is the possibility that dust could enter the pilot exhaust and damage the valve.

Ensure that the piping of exhaust air is not too restrictive.

#### Bracket

### A Caution

For bracket attached styles of SYJ300, do not use it without bracket.

1424



Be sure to read before handling.


Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

How to Use Plug Connector

# **▲** Caution

### 1. Attaching and detaching connectors


- To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.
- To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.



### 2. Crimping of lead wires and sockets

Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area.

Use an exclusive crimping tool for crimping. (Contact SMC for special crimping tools.)




# 3. Attaching and detaching sockets with lead wires

#### Attaching

Insert the sockets into the square holes of the connector (+, - indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then confirm that they are locked by pulling lightly on the lead wires.

#### Detaching

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1 mm). If the socket will be used again, first spread the hook outward.




### Plug Connector Lead Wire Length

### **▲** Caution

Standard length is 300 mm, but the following lengths are also available.

#### How to Order Connector Assembly



Include the connector assembly part number together with the part number for the plug connector's solenoid valve without connector.

Nil	300 mm
6	600 mm
10	1000 mm
15	1500 mm
20	2000 mm
25	2500 mm
30	3000 mm
50	5000 mm

EX.) In case of 2000 mm of lead wire


For DC	For AC
SYJ312-5LO-M3	SYJ312-1LO-M3
SY100-30-4A-20	SY100-30-1A-20

SYJ
VQZ
VP
VG
VP3🗆





Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.







Be sure to read before handling.

Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

Surge Voltage Suppressor


#### <For AC>

(There is no "S" type because the generation of surge voltage is prevented by a rectifier.)

# A Caution


### Grommet, L/M Plug Connector

#### With light (□Z)



### **DIN Terminal**

With light (DZ)



Note) Surge voltage suppressor of varistor has residual voltage corresponding to the protective element and rated voltage; therefore, protect the controller side from the surge. The residual voltage of the diode is approximately 1 V.

### **DIN Terminal Type Y**

A type Y DIN connector is a DIN connector conforming to the 8mm standard pitch between DIN terminals.

# **A** Caution

- Since a type D DIN connector has a 9.4-mm pitch between DIN terminals, it is not interchangeable.
- Type D DIN connectors have the "N" indication at the end of rated voltage symbol. (For DIN connectors without lights, "N" is not indicated. Please refer to the name plate to distinguish.)
  Dimensions are the same as type D DIN connector.
- When replacing only the pilot valve assembly, V115-□D is interchangeable with V115-□Y. Do not replace V111 (G, H, L, M, W) to V115-□Y (DIN terminal), or vice versa.

### How to Use DIN Terminal

# A Caution

#### Connection

- 1. Loosen the holding screw and pull the connector out of the solenoid valve terminal block.
- 2. After removing the holding screw, insert a flat head screwdriver, etc. into the notch on the bottom of the terminal block and pry it open, separating the terminal block and the housing.
- 3. Loosen the terminal screws (slotted screws) on the terminal block, insert the cores of the lead wires into the terminals according to the connection method, and fasten them securely with the terminal screws.

#### How to Use DIN Terminal

### **A** Caution

4. Secure the cord by fastening the ground nut.

### **▲** Caution

When making connections, take note that using other than the supported size ( $\emptyset$ 3.5 to  $\emptyset$ 7) heavy duty cord will not satisfy IP65 (enclosure) standards. Also, be sure to tighten the ground nut and holding screw within their specified torque ranges.

### Changing the entry direction

After separating the terminal block and housing, the cord entry can be changed by attaching the housing in the desired direction (4 directions at  $90^{\circ}$  intervals).


\* When equipped with a light, be careful not to damage the light with the cord's lead wires.

#### Precautions

Plug in and pull out the connector vertically without tilting to one side.

### Compatible cable

Cord O.D.: Ø3.5 to Ø7 (Reference) 0.5 mm<sup>2</sup>, 2-core or 3-core, equivalent to JIS C 3306



# SYJ VQZ VP VG

### **∧** Caution

Mount it so that there is no slippage or deformation in gaskets, and tighten with the tightening torque as shown below.

Solenoid Valve Mounting

Model	Thread size	Tightening torque				
SYJ300	M1.7	0.12 N•m				
SYJ500	M2.5	0.45 N•m				
SYJ700	M3	0.8 N•m				



Be sure to read before handling.

Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

### DIN Connector Part No.

# ▲ Caution


### <Type D>

Without light	SY100-61-1				
With light					
Rated voltage	Voltage symbol	Part no.			
24 VDC	24 V	SY100-61-3-05			
12 VDC	12 V	SY100-61-3-06			
100 VAC	100 V	SY100-61-2-01			
200 VAC	200 V	SY100-61-2-02			
110 VAC	110 V	SY100-61-2-03			
220 VAC	220 V	SY100-61-2-04			

### <Type Y>

Without light	SY100-82-1				
With light					
Rated voltage	Voltage symbol	Part no.			
DC24 V	24 VN	SY100-82-3-05			
DC12 V	12 VN	SY100-82-3-06			
100 VAC	100 VN	SY100-82-2-01			
200 VAC	200 VN	SY100-82-2-02			
110 VAC(115 VAC)	110 VN	SY100-82-2-03			
220 VAC(230 VAC)	220 VN	SY100-82-2-04			

### **Circuit Diagram with Light**




### Connector Assembly with Cover

# **≜**Caution


#### Connector assembly with dust proof protective cover.

- Effective to prevention of short circuit failure due to the entry of foreign matter into the connector.
- Chloroprene rubber for electrical use, which provides outstanding weather resistance and electrical insulation, is used for the cover material. However, do not allow contact with cutting oil, etc.
- Simple and unencumbered appearance by adopting round-shaped cord.

#### How to Order



### **Connector Assembly with Cover: Dimensions**



#### How to Order

Enter the part number for a plug connector solenoid valve without connector together with the part number for a connector assembly with cover.

- Ex. 1) Lead wire length of 2000 mm SYJ312-5LOZ-M3
  - SY100-68-A-20
- Ex. 2) Lead wire length of 300 mm (standard) SYJ312-5LPZ-M3

Symbol for connector assembly with cover

 In this case, the part number for the connector assembly with cover is not required.





Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

### **M8** Connector

# **≜**Caution

1. M8 connector types have an IP65 (enclosure) rating, offering protection from dust and water. However please note: these products are not intended for use in water.

Select a SMC connector cable (V100-49-1- $\Box$ ) or a FA sensor type connector, with M8 threaded 3 pin specifications conforming to Nippon Electric Control Equipment Association Standard, NECA4202 (IEC60947-5-2). Make sure the connector O.D. is 10.5 mm or less when used with the Series SYJ300 manifold. If more than 10.5 mm, it cannot be mounted due to the size.

- 2. Do not use a tool to mount the connector, as this may cause damage. Only tighten by hand. (0.4 to 0.6 N•m)
- 3. The excessive stress on the cable connector will not be able to satisfy the IP65 rating. Please use caution and do not apply a stress of 30 N or greater.

### **A** Caution

Failure to meet IP65 performance may result if using alternative connectors than those shown above, or when insufficiently tightened.

Connector cable mounting



Note) Connector cable should be mounted in the correct direction. Make sure that the arrow symbol on the connector is facing the triangle symbol on the valve when using SMC connector cable (V100-49-1-□). Be careful not to squeeze it in the wrong direction, as problems such as pin damage may occur.


### ■ Connector cable

• Connector cable for M8 can be ordered as follows:


#### How to Order

1. To order solenoid valve and connector cable at the same time.


(Connector cable will be included in the shipment of the solenoid valve.)




**W7**, **WA7**: Cable length 5000 mm



#### 2. To order connector cable only



Cable length (L)	Part no.
300 mm	V100-49-1-1
500 mm	V100-49-1-2
1000 mm	V100-49-1-3
2000 mm	V100-49-1-4
5000 mm	V100-49-1-7



SYJ
VQZ
VP
VG
VP3🗆



Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

**Replacement of Pilot Valve** 

# **≜**Caution

Pilot valves in this series are improved to provide excellent energy saving results. However following this improvement, these new valves are no longer compatible with the conventional pilot valve used at the interface. Consult with SMC when you need to exchange these pilot valves, in the case of manual override (marked in orange) of the adapter plate.

